

Blades Biological Ltd

COWDEN . EDENBRIDGE . KENT . UK . TN8 7DX

Telephone: (01342) 850242 . Fax: (01342) 850924

Email: info@blades-bio.co.uk Online: <http://www.blades-bio.co.uk/>

Plant Grow Lighting System

Instalation.

The unit is supplied with two screw eyes. With the unit dis connected from the power, screw the inserts into the back of the unit. The unit should then be suspended using strong cord or chain.

Troubleshooting.

If the system fails to start, disconnect from the power supply. Remove ant re insert the bulb/tubes and switch the unit back on. If the unit still dosent work please contact us for help.